



1 Expo Case has 2 wheels for easy transport.



2 Release the latches to open the case – press in the gray inner portion and swing out the black clasp.



3 Mount the counter top on the right hand side of the case. Align the slot on the underside of the shelf and press/lock the two latches.



4 Unfold the counter top to the left side. Align and lock in place with the two latches, as in the previous step.



5 Attach the 4 inner shelves by inserting into the slots in the case.



6 Attach the black kick-plate at the bottom of the desk.



7 Wrap the graphic panel around the front side of the counter and connect it with the 4 velcro strips.



### Technical information

#### Expo case contains:

- 1 Hard Case/Counter
- 1 Counter Top in a soft case
- 4 Inner Shelves in a soft case
- 4 Velcro Strip Fasteners
- 1 Kick Plate
- 1 Soft cases for top & shelves
- 1 Graphic tube for case wrap

#### Facts

Item no. 10604  
 Weight:  
 10 kg / 22 lbs. (case only)  
 19,5 kg / 43 lbs.  
 (case incl. top and 4 inner shelves)


#### Size folded

Height: 955 mm / 37.5"  
 Width: 640 mm / 25.2"  
 Depth: 400 mm / 15.7"

#### Size unfolded

Height: 965 mm / 38"  
 Width: 1245 mm / 49"  
 Depth: 600 mm / 23.6"

### Graphic banner production



Mount the 4 velcro strip fasteners in each corner on the reverse side of the graphic panel

### Packing (start)



#### Expo Case

- 1 Bag for counter top (incl. with case)
- 2 Bag for inner shelves (incl. with case)

### Packing (add-on)



#### ISOframe Wave (5 Wave Flex-Link modules)

- 1 1 Small graphic tube, item IS-0800-RTS-S-MB
- 2 2 Post bags, item IS-5056
- 3 1 Foot bag, item IS-5055
- 4 1 Flexi-Link, item IS-5054



#### SnapUp (Classic & Elegance)

- 1 1 Small graphic tube, item IS-0800-RTS-S-MB
- 2 1 Bag for system, item 5045
- 3 1 Bag for mag-bars (incl. with system)
- 4 1 Spotlight bag, item 80021



#### BannerUp 88

- 1 3 BannerUp 88/3 ft. with bags, item 81115
- 2 1 Graphic tube for case wrap (incl. with case)